PREPARATION


IMPORTANT:

Familiarize yourself with your new iClean mini.

Your iClean mini kit includes:

- iClean mini device
- USB charging cord
- Instruction sheet
- Gift box

CHARGE



ersan (


Charging port

Waterpipe

- The charging port is located on the back of the iClean mini.
- · Connect the USB charging cord to the device.
- Plug the other end of the charging cord into a USB outlet or through a USB power adapter (not included) then into a standard electrical outlet.
- A slowly flashing red light on top indicates charging is taking place.
- Charging is complete when a blue light on top flashes.
- Unplug the charging cord from the outlet and disconnect the charger from the iClean.

Note: If iClean mini does not operate when activation button is pressed, the iClean mini needs to be recharged. iClean mini will not operate during the charging process.

FILL



- Turn reservoir on base counter-clockwise and remove from iClean mini.
- · Fill reservoir with cold tap water ONLY.
- Reattach reservoir to iClean mini and turn clockwise to fasten tightly.
- · Fill with tap water ONLY.
- · Do NOT add chemicals or soap.
- · Do not submerge under water.

USE

INDICATORS

- When activation button is pressed, a continuous blue light on top indicates iClean mini is producing aqueous ozone.
- A continuous red light on top indicates reservoir is empty.

CLEAN

- Press activation button on front of iClean mini to wet surface to be cleaned.
- Wipe surface dry with a cotton, microfiber, or paper textile.

Note: no need to wipe completely dry – residual water will evaporate without streaking.

SANITIZE

- · Kill germs only on hard, non-porous surfaces.
- · Clean surface with the iClean mini.
- Press button and continuously spray surface with aqueous ozone.
- · Wipe surface dry with any clean cloth.

CARE

RECHARGING

- It is not necessary to drain battery completely before recharging.
- ONLY use charger supplied with iClean mini kit.

MAINTENANCE

To maintain consistent performance, follow these care instructions.

- · Empty reservoir at the end of each day.
- With empty reservoir attached, press activation button for 5 seconds to clear excess water.
- When iClean mini has not been used for more than 5 days, fill reservoir completely, press activation button, and spray until reservoir is empty. Then refill reservoir and iClean mini is ready for use again.
- Use only attachments and replacement parts sold or recommended by manufacturer.
- · iClean mini is NOT dishwasher safe.
- iClean mini is not a toy. Supervision required when children present.

STORAGE

- · Empty water from reservoir.
- Store upright at room temperature.
- Do not dispose of device or battery in household trash. Dispose of properly. Contact Tersano with questions.
- Store upright and indoors above 40°.

Product may vary slightly from illustrations enclosed in this use and care guide.

CAUTION

- For first time usage, charge for 4 hours and then spray at least one tank of water to activate the unit in order to achieve the normal concentration value of O₃ water.
- · Do not spray directly into the eyes.
- · Avoid flushing the unit with water.





Powered by **Bluamec**

QUESTIONS OR CONCERNS

Contact Tersano at 800-727-8835 or +1 519 737 7588 with questions or concerns about your iClean mini.



REPLACEMENT SAO™ CARTRIDGES

Ensures iClean mini Sanitizes and Deodorizes One filter lasts over 1,000 sprays





Product may vary slightly from illustrations enclosed in this use and care guide.

